

HOW TO INSTALL NEW HOLLAND CR ROTARY CONCAVES




22" CR CONCAVES



Extension grates require different inserts than the concave.


Adding extension grates to the rotary concave can maximize its threshing abilities.




Left Hand Concave



Right Hand Insert



Right Hand Concave



Left Hand Insert

1 Complete Set

When you order a complete set you receive: 2 main tri-frames, 8 modules (4 per side), and 2 extension grates for both LH & RH sides.

3 Bolt Together

Once modules are in the main frame bolt into place. Modules with smaller holes should be at the front of the concave transitioning to larger holes towards the back of the concave. There are 6 bolts to affix the modules into place, and 2 additional bolts to bolt the centers of each module into place.

2

Installation

Remove modules from the main tri-frame and install the Sunnybrook main triframe. *Note* frame is reversible between left and right. After frame is installed, insert modules onto the pins on the main frame and bolt into place.

IMPORTANT

A left concave requires right hand inserts and a right concave requires left hand inserts. WHY? To ensure the crop bounces against the threshing bar of the insert. Putting the insert on the wrong side will not produce any threshing action.

NEED ASSISTANCE

SETUP OPTIONS

HARD THRESHING

1. Boron Max Thresh



2. Regular Max Thresh



3. Round Bar



STANDARD THRESHING

1. Regular Max Thresh



2. Regular Max Thresh



3. Round Bar



EASY THRESHING

1. Regular Max Thresh



2. Round Bar



3. Round Bar



SUPER EASY THRESHING

1. Round Bar



2. Round Bar



3. Round Bar



IMPORTANT:
Same setup for LH
& RH.

PLEASE NOTE: LH
concave requires
right hand
modules, RH
concave requires
left hand modules.